

ICOS

The Ultimate Blu-Ray Upgrade

BDP-S

Series

User Instructions

Introduction

This Upgrade is an advanced modification to your Blu-Ray player, which adds extra features and enables you to get more from your machine. The upgrade supplements the Blu-Ray player and in no way harms the playback quality or removes any performance features of the machine.

BluRay Players supported

- Sony BDP-S1200/3200/4200/5200/6200/7200/1500/4500/5500. BDV-N5200/7200

Features of the Upgrade

Multiregion selection

Blu-Ray discs on the market today can be encoded with a specific "region" in mind and are made in such a way that a disc designed for "region A" will not play on a player designed for "region B". This is so that the Hollywood studios can control the release of titles in different geographical regions all over the world. Our upgrade allows you to manually switch your Blu-Ray player between regions A,B & C

Operating Instructions

Turn the player off with the remote control and wait till there is no display or light showing.

Press one of the following buttons on the player's remote to select the Blu-Ray region required.

Region Required	Press
Region A (USA Canada & Japan)	RED
Region B (Europe & Australia)	GREEN
Region C	YELLOW

The player will automatically power up.

Eject the tray, place disc in and play.

The player will remain in that region until another region is selected.

DVD Region code is done automatically.

Please note:-

Blu-ray region switching will not work while quick start is enabled.