

---

## User Instructions

### **Introduction**

This Upgrade is an advanced modification to your Blu-Ray player, which adds extra features and enables you to get more from your machine. The upgrade supplements the Blu-Ray player and in no way harms the playback quality or removes any performance features of the machine.

### **Features of the Upgrade**

#### **Multiregion selection**

Nearly all DVD & Blu-Ray discs on the market today are encoded with a specific "region" in mind and are made in such a way that a disc designed for "region A" will not play on a player designed for "region B". This is so that the Hollywood studios can control the release of titles in different geographical regions all over the world. Our upgrade allows you to manually switch your Blu-Ray player between regions A, B & C.

The Modification enables Multiregional DVD Playback which is automatic, Blu-ray needs to be manually selected as follows,

### **Operating Instructions**

Firstly eject the disc and remove it from the tray, then Turn the player off with the remote control so there is no display or LED showing, press one of the following buttons on the remote to select the required Blu-ray region.

<b>Region Required</b>	<b>Key</b>
Region A	1
Region B	2
Region C	3

The machine will automatically power up.

Eject the tray, place disc in and press play.

**Quickstart must be left turned off when setting up the player for the region switching to work.**